

COLD SPACE TEMPERATURE TRANSMITTER TEKY4 LU

TEKY4 LU temperature transmitter is designed for cold space temperature measurement in automatic HVAC systems.

The temperature is detected by a Pt1000 sensor element. The sensor element resistance information is converted to a 0...10 V signal. The temperature range can be chosen at the commissioning.

The transmitter settings can be changed by using the ML-SER commissioning tool. The tool can be used to make one point field calibration and to change the temperature output to controller output.

The transmitter can be equipped with a display that has resolution of 0.1 °C.

Selecting the measuring range

0...+50 °C	0...+100 °C	*-50...+50 °C	-50...+150 °C
S1 S2	S1 S2	S1 S2	S1 S2
■ ●	■ ■	● ●	● ●

* = Factory setting

Output signal

0...50	0...100	-50...50	-50...150	Signal
0 °C	0 °C	-50 °C	-50 °C	0 V
25 °C	50 °C	0 °C	50 °C	5 V
50 °C	100 °C	50 °C	150 °C	10 V

Wiring



Technical data

Supply	24 Vac/dc (22...30 V) < 1 VA
Sensor element	Pt1000 EN60751/B
Ranges	0...50 °C 0...100 °C -50...50 °C -50...150 °C
Accuracy	±0.5 °C (at 0 °C)
Output	0...10 Vdc, < 2 mA
Measuring probe	
sleeve	∅ 4 mm x 30 mm, stainless steel
cable	∅ 3.2 mm x 2.3 m
material	PVC
protection class	IP67
Ambient temperature	-30...+80 °C
Housing	
protection class	IP54 (cable gland downwards)
cable gland	M16
Ambient temperature	-30...60 °C

Ordering guide:

Model	Product number	Description
TEKY4 LU	1179330	3-wire, 0...10 V temperature transmitter for cold spaces
TEU-N V2	1170270	display cover for LL and LU transmitters
ML-SER	1139010	transmitter commissioning tool

Products fulfil the requirements of directive 2004/108/EC and are in accordance with the standards EN61000-6-3: 2001 (Emission) and EN61000-6-2: 2001 (Immunity).